

YOUR MYSTAR REMOTE CONTROL

MyStar Remote Control

Below is a quick reference guide to features and services you can access using the MyStar remote control.

- 
- 1 [on/standby]
Puts MyStar into or out of standby
- 2 [AUSTAR]
Returns you to the last channel you were watching
- 3 [music]
Takes you to the Air application
- 4 [tv guide]
Displays your on-screen TV Guide
- 5 [planner]
Displays Planner
- 6 [active]
Displays the Active menu for AUSTAR's range of interactive services
- 7 [box office]
To order movies and events from the AUSTAR Box Office
- 8 [setup]
Displays the Setup menu to alter MyStar settings
- 9 [i]
Displays more information about a program
- 10 [vol +] / [vol -]
Changes the volume up or down
- 11 [ch +] / [ch -]
Changes the channel up or down
- 12 [arrow buttons]
Moves the on-screen highlight around the screen
- 13 [select]
Confirms a choice or makes a selection
- 14 [mute]
Turns the sound on or off
- 15 [back]
Returns you to the previous screen
- 16 [help]
Displays help information
- 17 [pause]
Pauses the program or starts a "Live Pause" recording
- 18 [play]
Plays a recorded program
- 19 [rewind]
Rewinds the program
- 20 [fast forward]
Fast forwards the program
- 21 [record]
Records the program
- 22 [stop]
Stops playback of the program
- 23 colour buttons
Use to select the matching colour option shown on-screen, as explained in this User Manual
- 24 number buttons (0-9)
Use to change channel, and select on-screen options